










HELIX® Cable	EZfit® Connectors	Universal Hand Prep Tool	Drill Tool for HELIX AL	Drill Tool for HELIX CU	Wrenches: Back Nut/ Front Nut
3/8" Superflexible					
SFX-500 HELIX AL	SFX EZfit® Series SFXEZN, SFXEZN*, SFXEZDM, SFXEZDM*, SFXEZN*, SFXEZDM*	Hand Prep Tool not available for SFX-500.	SFX-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For SFX-500 cable only. Supplied with T-handle for hand use.	3/8" HELIX CU Cable/Drill Tool not available	EZW-7812 Combination Wrench  TW-SFX-EZFC Torque Wrench 
1/2"					
FXL-540 HELIX AL LDF4-50A HELIX CU	540 and 12 EZfit® Series 540EZDF*, 540EZDM*, 12EZDMR, 540EZN*, 540EZN*, 12EZNMR (*Only compatible with FXL-540 cable)	12-HPT The 1/2 inch hand prep tool removes jacketing, cores foam and flares sheath for easy connector attachment. Includes bits for FXL-540 and LDF4 cables. Drill not required.	540-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For FXL-540 cable only. Supplied with T-handle for hand use.	L4-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For LDF4 cable only. Supplied with T-handle for hand use.	EZW-7812 Combination Wrench  TW-12-EZFC Torque Wrench 
7/8"					
FXL-780 HELIX AL AVA5-50 HELIX CU	78 EZfit® Series: 78EZDF, 78EZDM, 78EZN*, 78EZN*	78-HPT The 7/8 inch hand prep tool removes jacketing, cores foam and flares sheath for easy connector attachment. Includes bits for FXL-780 and AVA5 series cables. Drill not required.	780-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For FXL-780 cable only. Supplied with T-handle for hand use.	A5-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For AVA5 cable only. Supplied with T-handle for hand use.	EZW-7812 Combination Wrench  TW-78-EZFC Torque Wrench 
1-1/4"					
FXL-1480 HELIX AL AVA6-50 HELIX CU	114 EZfit® Series: 114EZDF, 114EZDM, 114EZN*, 114EZN*	Hand prep tool not available for 1-1/4" cable.	1480-PT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For FXL-1480 cable only. Supplied with T-handle for hand use.	A6-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For AVA6 cable only. Supplied with T-handle for hand use.	1480-AW 1-3/4" (45 mm) Wrench  TW-114-EZFC Torque Wrench 
1-5/8"					
FXL-1873 HELIX AL AVA7-50 HELIX CU	158 EZfit® Series: 158EZDF, 158EZDM, 158EZN*, 158EZN*	Hand prep tool not available for 1-5/8" cable.	FXL/CR 1873-PT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For FXL-1873 cable only. Supplied with T-handle for hand use.	A7-EZPT Drill driven tool removes jacketing, cores foam and flares sheath. Speeds connector attachment. For AVA7 cable only. Supplied with T-handle for hand use.	1873-AW 2-3/8" (60 mm) Wrench  TW-158-EZFC Torque Wrench 